


Globe Valve - Page 1 of 1



:

When repair is beyond lower level maintenance capability evacuate the item to depot disposal is not authorized below wholesale level